


TERMINALS OF ECU



H01357

No.	Symbol	Terminal Name
A	-	Electrical Connector Check Mechanism
B	-	Electrical Connector Check Mechanism
C3 - 1	PL-	Squib (Seat Belt Pretensioner, LH)
C3 - 2	PL+	Squib (Seat Belt Pretensioner, LH)
C5 - 3 (*1)	DMR+	Door Side Airbag Sensor (RH)
C5 - 4 (*1)	DMR-	Door Side Airbag Sensor (RH)
C3 - 5 (*2)	SFL+	Squib (Side, LH)
C3 - 6 (*2)	SFL-	Squib (Side, LH)
C3 - 7 (*2)	VUPL	Side Airbag Sensor (LH)
C3 - 9 (*2)	SSL+	Side Airbag Sensor (LH)
C3 - 10 (*2)	FSL	Side Airbag Sensor (LH)
C3 - 11 (*3)	LBE+	Body ECU
C3 - 12 (*2)	ESL	Side Airbag Sensor (LH)
C4 - 3	LA	SRS Warning Light
C4 - 5	IG2	Power Source
C4 - 6	IG1	Power Source
C4 - 9	+SR	Front Airbag Sensor (RH)
C4 - 10	P+	Squib (Passenger)
C4 - 11	P-	Squib (Passenger)
C4 - 12	SIL	Diagnosis
C4 - 13	D-	Squib (Driver)
C4 - 14	D+	Squib (Driver)
C4 - 15	+SL	Front Airbag Sensor (LH)
C4 - 19	Tc	Diagnosis
C4 - 20	-SR	Front Airbag Sensor (RH)

No.	Symbol	Terminal Name
C4 - 26	-SL	Front Airbag Sensor (LH)
C4 - 27	E1	Ground
C4 - 28	E2	Ground
C5 - 1 (*2)	SFR-	Squib (Side, RH)
C5 - 2 (*2)	SFR+	Squib (Side, RH)
C3 - 3 (*1)	DML-	Door Side Airbag Sensor (LH)
C3 - 4 (*1)	DML+	Door Side Airbag Sensor (LH)
C5 - 5	PR+	Squib (Pretensioner, RH)
C5 - 6	PR-	Squib (Pretensioner, RH)
C5 - 7 (*2)	ESR	Side Airbag Sensor (RH)
C5 - 9 (*2)	FSR	Side Airbag Sensor (RH)
C5 - 10 (*2)	SSR+	Side Airbag Sensor (RH)
C5 - 12 (*2)	VUPR	Side Airbag Sensor (RH)

*1 : 2-Door Models

*2 : w/ Side Airbag

*3 : w/o Side Airbag