



## INSPECTION

1. **REMOVE THROTTLE BODY**  
(See page [SF-34](#) )
2. **REMOVE INTAKE MANIFOLD**  
(See page [EM-28](#) )



3. **REMOVE KNOCK SENSOR**
  - (a) Disconnect the knock sensor connector.
  - (b) Using SST, remove the knock sensor.  
SST 09816-30010



4. **INSPECT KNOCK SENSOR**

Using an ohmmeter, check that there is continuity between the terminal and body.  
If there is continuity, replace the sensor.
5. **REINSTALL KNOCK SENSOR**
  - (a) Using SST, install the knock sensor.  
SST 09816-30010
  - (b) Connect the knock sensor connector.
6. **REINSTALL INTAKE MANIFOLD**  
(See page [EM-44](#) )
7. **REINSTALL THROTTLE BODY**  
(See page [SF-36](#) )