


DISASSEMBLY

1. REMOVE NO. 2 FUEL SUCTION SUPPORT

- Using a small screwdriver, remove the No. 2 fuel suction support.
- Remove the rubber cushion and fuel pressure regulator.
- Remove the O-ring from the pressure regulator.



2. REMOVE NO. 1 FUEL SUCTION SUPPORT

- Disconnect the fuel sender gauge connector.
- Using a small screwdriver, remove the No. 1 fuel suction support.


NOTICE:

Do not damage the fuel suction support and fuel suction plate.

- Disconnect the fuel pump harness from the fuel pump.
- Remove the O-ring from the No. 1 fuel suction support.

3. REMOVE VAPOR PRESSURE SENSOR

Pull off the joint clip and remove the vapor pressure sensor from No. 1 fuel suction support.



4. REMOVE FUEL PUMP

- Remove the fuel pump from the fuel filter.
- Remove the O-ring from the fuel pump.