


DISASSEMBLY

1. REMOVE VALVE LIFTERS

HINT:

Arrange the valve lifters in the correct order.




2. REMOVE VALVES


- (a) Using SST, compress the valve spring and remove the 2 keepers.

SST 09202-70020 (09202-00010)

- (b) Remove the spring retainer.
 (c) Remove the valve spring.
 (d) Remove the valve.



- (e) Using needle-nose pliers, remove the oil seal.



- (f) Using compressed air and a magnetic finger, remove the spring seat by blowing air.

HINT:

Arrange the valves, valve springs, spring seats and spring retainers in the correct order.