



## INSTALLATION

### 1. CHECK TORQUE CONVERTER CLUTCH INSTALLATION

Using calipers and a straight edge, measure the distance from the installed surface of the transaxle housing to the torque converter clutch.

**Correct distance: 9.3 mm (0.366 in.)**

### 2. TRANSAXLE INSTALLATION

Installation is in the reverse order of removal (See page [AX-29](#) ).

HINT:

- After installation, adjust the park/neutral position switch (See page [DI-149](#) ).
- Fill ATF and check fluid level (See page [DI-149](#) ).
- Do test to drive the vehicle (See page [DI-149](#) ).