


INSTALLATION

NOTICE:

- Never use SRS parts from another vehicle. When replacing parts, replace them with new ones.
- Never reuse the side airbag sensor assembly involved in a collision when the airbag has deployed.
- Never repair a sensor in order to reuse it.

HINT:

For step 2 to 4, refer to page [BO-1 10](#).



1. INSTALL SIDE AIRBAG SENSOR ASSEMBLY

- Install the side airbag sensor assembly with the 3 bolts.
Torque: 20 N·m (205 kgf-cm, 15 ft-lbf)
- Connect the side airbag sensor assembly connector.

NOTICE:

- Connection of the connector is done after the sensor assembly has been installed. Make sure the sensor assembly is installed with the specified torque.
 - If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
 - When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
 - After installation, shake the sensor assembly to check that there is no looseness.
- INSTALL RETRACTOR PART OF FRONT SEAT OUTER BELT
 - INSTALL CENTER PILLAR LOWER GARNISH
 - INSTALL FRONT AND REAR DOOR SCUFF PLATES