



## REMOVAL

### 1. DISCONNECT CLUTCH LINE

(a) Using SST, disconnect the clutch line.

SST 09023-00100

(b) Use a container to catch the fluid.

### 2. REMOVE 2 BOLTS AND PULL OUT RELEASE CYLINDER