


## DISASSEMBLY

### 1. w/o Power window:


#### REMOVE REGULATOR HANDLE

Pull off the snap ring with a shop rag and remove the regulator handle and plate.



#### HINT:

At the time of reassembly, please refer to the following item.  
With door window fully closed, install the plate and the regulator handle with the snap ring.



### 2. REMOVE DOOR TRIM

- Remove the screw and pull handle.
- Remove the screw.
- Insert a screwdriver between the door panel and door trim to pry the trim out.


#### NOTICE:

**Be careful not to damage the door panel and trim.**

#### HINT:


Tape the screwdriver tip before use.

- Pull the door trim upward to remove it.
- w/ Power window:  
Disconnect the power window switch connector.
- w/ Power window:  
Remove the power window switch from the door trim.



### 3. REMOVE INNER WEATHERSTRIP

Remove the inner weatherstrip as shown in the illustration.



### 4. REMOVE DOOR INSIDE HANDLE

- Remove the door inside handle in order A, B as shown in the illustration.
- Disconnect the door lock cable from the door inside handle.

### 5. REMOVE PULL HANDLE BRACKET

Remove the 2 screws and pull handle bracket.


### 6. REMOVE SERVICE HOLE COVER

Remove the service hole cover.

HINT:

At the time of reassembly, please refer to the following item.  
Bring out the cable through the service hole cover.

### 7. REMOVE INSIDE PANEL REINFORCEMENT



### 8. REMOVE DOOR BELT MOULDING

Using a scraper, remove the door belt moulding.

HINT:

Tape the scraper tip before use.


### 9. REMOVE QUARTER WINDOW GLASS

- Remove the door glass run.


HINT:

Pull the glass run upward.

- Remove the glass stop.



- (c) Turn over the weatherstrip and remove the screw.
- (d) Remove the 2 bolts and division bar.
- (e) Remove the quarter window glass with weatherstrip.
- (f) Remove the weatherstrip from the quarter window glass.



#### 10. REMOVE DOOR GLASS

- (a) Slide out the door glass from the window regulator.

#### NOTICE:

**Be careful not to drop the door glass.**

- (b) Pull the door glass upward to remove it.

#### 11. REMOVE WINDOW REGULATOR

- (a) w/ Power window:  
Disconnect the connector, then remove the 4 bolts and window regulator.


**Torque: 8.3 N·m (85 kgf-cm, 74 in.-lbf)**

- (b) w/o Power window:  
Remove the 3 bolts and window regulator.

**Torque: 8.3 N·m (85 kgf-cm, 74 in.-lbf)**

#### HINT:

Remove the regulator through the service hole.




#### HINT:

At the time of reassembly, please refer to the following item.  
Apply MP grease to the window regulator.

#### NOTICE:

**At the time of reassembly, please refer to the following item.**

**Do not apply grease to the spring of the window regulator.**

**12. REMOVE DOOR LOCK**


- (a) Remove the door lock control knob.
- (b) Remove the door lock control bellcrank and disconnect the 2 door lock control links.
- (c) Disconnect the door lock control link and cable from the door lock link clamp.
- (d) w/ Power door lock:  
Disconnect the connector and remove the bolt, 3 screws and door lock with control links.  
**Torque: 4.9 N·m (50 kgf-cm, 43 in.-lbf)**
- (e) w/o Power door lock:  
Remove the 3 screws and door lock with control links.  
**Torque: 4.9 N·m (50 kgf-cm, 43 in.-lbf)**

**HINT:**

At the time of reassembly, please refer to the following item.  
Apply adhesive to 3 screws.

**Part No. 08833-00070, THREE BOND 1324 or equivalent**

- (f) Remove the door lock through the service hole.

**HINT:**

At the time of reassembly, please refer to the following item.  
Apply MP grease to the sliding and rotating parts of the door lock.

**13. REMOVE DOOR LOCK LINK GUIDE AND CLAMP**

Using a screwdriver, remove the door lock link guide and clamp.

**HINT:**

Tape the screwdriver tip before use.

**14. REMOVE OUTSIDE HANDLE**

Remove the 2 bolts and outside handle.

**Torque: 5.4 N·m (55 kgf-cm, 48 in.-lbf)**