



REMOVAL

1. REMOVE THROTTLE BODY
(See page [SF-34](#))

2. REMOVE IAC VALVE

Remove the 4 screws, IAC valve and gasket.