


REMOVAL

NOTICE:


Face the front wheel straight ahead to prevent damage to the steering gear.

1. REMOVE FRONT WHEEL




2. DISCONNECT FLEXIBLE HOSE AND ABS SPEED SENSOR WIRE HARNESS CLAMP

Remove the bolt and disconnect the flexible hose and ABS speed sensor wire harness clamp from the shock absorber bracket.



3. REMOVE SHOCK ABSORBER WITH COIL SPRING

(a) Remove the 2 nuts and bolts, and disconnect the shock absorber from the steering knuckle.



(b) Remove the 3 nuts and shock absorber with the coil spring.