

INSTALLATION

1. INSTALL ELECTRIC COOLING FAN TO RADIATOR

Install the cooling fan with the 3 bolts.

Torque: 7.5 N·m (80 kgf·cm, 66 in.-lbf)

2. INSTALL RADIATOR ASSEMBLY

- (a) Install the 2 radiator support cushions and grommets to the radiator.
- (b) Attach the 2 grommets on the radiator to the body brackets.
- (c) Install the upper radiator supports with the 7 (w/o A/C) or 9 (w/ A/C) bolts.
- (d) Connect the upper radiator hose.
- (e) Connect the lower radiator hose.
- (f) Connect the radiator reservoir hose.
- (g) A/T:
Connect the 2 oil cooler hoses to the oil cooler pipes.
- (h) Install the radiator cover with the 2 clips.
- (i) Connect the horn connector.
- (j) Connect the electric cooling fan connector.

3. INSTALL ENGINE UNDER COVERS

4. FILL WITH ENGINE COOLANT

5. START ENGINE AND CHECK FOR COOLANT LEAKS