

## INSTALLATION

### 1. w/ Side mudguard:

#### INSTALL SIDE MUDGUARD

#### (a) 2-Door vehicle:

Clean the body mounting surface.

(1) Using a heat light, heat the body mounting surface to 40 - 60°C (104 - 140°F).

(2) Remove the adhesive tape from the body.

(3) Wipe off stains with cleaner.

#### (b) Install the 4 bolts and side mudguard No. 2 retainer.

#### (c) Install the side mudguard.

#### (1) 2-Door vehicle:

Using a heat light, heat the body and moulding.

**Body: 40 - 60°C (104 - 140°F)**

**Moulding: 20 - 30°C (68 - 86°F)**

#### NOTICE:

**Do not heat the moulding excessively.**

#### (2) 2-Door vehicle:

Lift the moulding release sheet from face of moulding.

#### NOTICE:

**When the moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.**

(3) Install the 3 bolts and screw.

(4) Align the bosses with their corresponding holes in the body and press firmly on the moulding.

#### NOTICE:

**Do not apply excessive force onto the moulding, but steady pressure with your thumbs.**

### 2. 4-Door vehicle:

#### INSTALL QUARTER OUTSIDE REAR MOULDING

#### (a) Clean the body mounting surface.

(1) Using a heat light, heat the body mounting surface to 40 - 60°C (104 - 140°F).

(2) Remove the adhesive tape from the body.

(3) Wipe off stains with cleaner.

#### (b) Install the quarter outside rear moulding.

(1) Using a heat light, heat the body and moulding.


**Body: 40 - 60°C (104 - 140°F)**

**Moulding: 20 - 30°C (68 - 86°F)**

#### NOTICE:

**Do not heat the moulding excessively.**

(2) Lift the moulding release sheet from face of moulding.



**NOTICE:**

**When the moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.**


- (3) Align the bosses with their corresponding holes in the body and press firmly on the moulding.

**NOTICE:**

**Do not apply excessive force onto the moulding, but steady pressure with your thumbs.**

**3. 2-Door vehicle:****INSTALL QUARTER OUTSIDE REAR MOULDING**

- (a) Clean the body mounting surface.
  - (1) Using a heat light, heat the body mounting surface to 40 - 60°C (104 - 140°F).
  - (2) Remove the adhesive tape from the body.
  - (3) Wipe off stains with cleaner.



- (b) Install the quarter outside rear moulding.
  - (1) Using a heat light, heat the body and moulding.  
**Body: 40 - 60°C (104 - 140°F)**  
**Moulding: 20 - 30°C (68 - 86°F)**

**NOTICE:**

**Do not heat the moulding excessively.**

- (2) Lift the moulding release sheet from face of moulding.

**NOTICE:**

**When the moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.**


- (3) Align the bosses with their corresponding holes in the body and press firmly on the moulding.

**NOTICE:**

**Do not apply excessive force onto the moulding, but steady pressure with your thumbs.**

**4. 4-Door vehicle:****INSTALL REAR DOOR LOWER OUTSIDE MOULDING**

- (a) Clean the body mounting surface.
  - (1) Using a heat light, heat the body mounting surface to 40 - 60°C (104 - 140°F).
  - (2) Remove the adhesive tape from the body.
  - (3) Wipe off stains with cleaner.



- (b) Install the rear door lower outside moulding.
- (1) Using a heat light, heat the body and moulding.  
**Body: 40 - 60°C (104 - 140°F)**  
**Moulding: 20 - 30°C (68 - 86°F)**

**NOTICE:**

**Do not heat the moulding excessively.**

- (2) Lift the moulding release sheet from face of moulding.

**NOTICE:**

**When the moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.**


- (3) Align the bosses with their corresponding holes in the body, and press firmly on the moulding.

**NOTICE:**

**Do not apply excessive force onto the moulding, but steady pressure with your thumbs.**

**5. 4-Door vehicle:****INSTALL FRONT DOOR LOWER OUTSIDE MOULDING**

- (a) Clean the body mounting surface.
- (1) Using a heat light, heat the body mounting surface to 40 - 60°C (104 - 140°F).
  - (2) Remove the adhesive tape from the body.
  - (3) Wipe off stains with cleaner.



- (b) Install the front door lower outside moulding.
- (1) Using a heat light, heat the body and moulding.  
**Body: 40 - 60°C (104 - 140°F)**  
**Moulding: 20 - 30°C (68 - 86°F)**

**NOTICE:**

**Do not heat the moulding excessively.**

- (2) Lift the moulding release sheet from face of moulding.

**NOTICE:**

**When the moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.**


- (3) Align the bosses with their corresponding holes in the body, and press firmly on the moulding.

**NOTICE:**

**Do not apply excessive force onto the moulding, but steady pressure with your thumbs.**

**6. 2-Door vehicle:****INSTALL FRONT DOOR LOWER OUTSIDE MOULDING**

- (a) Clean the body mounting surface.
- (1) Using a heat light, heat the body mounting surface to 40 - 60°C (104 - 140°F).
  - (2) Remove the adhesive tape from the body.
  - (3) Wipe off stains with cleaner.



- (b) Install the front door lower outside moulding.
- (1) Using a heat light, heat the body and moulding.  
**Body: 40 - 60°C (104 - 140°F)**  
**Moulding: 20 - 30°C (68 - 86°F)**

**NOTICE:**

**Do not heat the moulding excessively.**

- (2) Lift the moulding release sheet from face of moulding.

**NOTICE:**

**When the moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.**


- (3) Align the bosses with their corresponding holes in the body, and press firmly on the moulding.

**NOTICE:**

**Do not apply excessive force onto the moulding, but steady pressure with your thumbs.**

**7. INSTALL FRONT FENDER OUTSIDE MOULDING**

- (a) Clean the body mounting surface.
- (1) Using a heat light, heat the body mounting surface to 40 - 60°C (104 - 140°F).
  - (2) Remove the adhesive tape from the body.
  - (3) Wipe off stains with cleaner.



- (b) Install the front fender moulding.
- (1) Using a heat light, heat the body and moulding.  
**Body: 40 - 60°C (104 - 140°F)**  
**Moulding: 20 - 30°C (68 - 86°F)**

**NOTICE:**

**Do not heat the moulding excessively.**

- (2) Lift the moulding release sheet from face of moulding.

**NOTICE:**

**When the moulding release sheet is removed, make sure that no dirt or dust can get onto the uncoated area.**

- (3) Align the bosses with their corresponding holes in the body, and press firmly on the moulding.

**NOTICE:**

**Do not apply excessive force onto the moulding, but steady pressure with your thumbs.**

- (4) Install the 3 screws.
- (c) Install the fender liner.

**8. w/ Front spoiler:**

**INSTALL FRONT SPOILER (See page [BO-4](#) )**