


INSTALLATION

1. INSTALL RELEASE CYLINDER WITH 2 BOLTS

Torque: 12 N·m (120 kgf-cm, 9 ft-lbf)



2. CONNECT CLUTCH LINE

Using SST, connect the clutch line.

SST 09023-00100

Torque: 15 N·m (155 kgf-cm, 11 ft-lbf)

3. FILL CLUTCH RESERVOIR WITH BRAKE FLUID AND BLEED CLUTCH SYSTEM

4. CHECK FOR LEAKS