

INSTALLATION


1. INSTALL MASTER CYLINDER

Install the master cylinder to the body with the 2 nuts.

Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)

2. INSTALL CLEVIS PIN, CLIP AND RETURN SPRING

- (a) Install the clevis pin.
- (b) Using needle-nose pliers, install the clip.
- (c) Using needle-nose pliers, install the return spring.



3. CONNECT CLUTCH LINE TO MASTER CYLINDER

Using SST, connect the clutch line.

SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)

4. CONNECT RESERVOIR HOSE TO MASTER CYLINDER

Connect the reservoir hose to the inlet union and using pliers, install the clip.

5. w/ ABS:

INSTALL ABS ACTUATOR (See page [BR-37](#))

6. FILL RESERVOIR WITH BRAKE FLUID AND BLEED CLUTCH SYSTEM

7. CHECK FOR LEAKS

8. ADJUST CLUTCH PEDAL (See page [CL-2](#))

9. FILL BRAKE FLUID UP TO MAX. LINE ON RESERVOIR

10. INSTALL FILLER CAP TO RESERVOIR